



Stop!
Take Care

IMPORTANT!

Please read **both sides** of this leaflet carefully before you remove from APV

Care and Maintenance Instructions

This P-Valve will give you many years of trouble free service and is backed up by a *lifetime warranty.

If you do not ensure that the valve is kept clean and free from the build up of grit salt or any foreign object, **it will leak**.

Flush through with fresh water after every use.



Occasionally replace fresh water with a very mild diluted solution of anti-bacterial fluid.



Look after your APV, and it will look after you.

*Conditions apply. Please go to www.othree.co.uk/warranty for full details.



Stop!
Take Care

IMPORTANT!
Please read **both sides** of
this leaflet carefully before
you remove from APV

Explanation

Your O'Three Advanced P-Valve has been expertly fitted to your suit and is supplied to you with the Dome Cover turning freely. This will allow the non-return valve which sits under the dome cover to operate unhindered.

It is this non-return valve that allows urine to exit, whilst preventing water from entering the P-Valve tube.

The Dome Cover

The Dome Cover is not required to operate the valve. The purpose of the dome cover is to protect and if necessary, block the non-return valve. Please ensure that the dome cover is turning freely in normal use.

Blocking

In the unlikely event that the non-return valve fails, simply rotate the dome cover clock-wise, lightly tightening until it stops. This will block the mushroom valve and stop any further ingress of water.

Do not over tighten.

www.othree.co.uk/apv-care-maintenance



www.othree.co.uk | T: +44 (0) 1305 822820
Osprey Quay Portland Dorset UK DT5 1BL

APV
ADVANCED P-VALVE